



Mt-Pro Firmware (Slave) – Manual ‘re-flash’

In the event of the Mt-Pro failing to complete an automatic firmware (Slave) re-flash procedure the following method can be used to:

- 1) By-pass the ‘automatic’ update process
- 2) Manually force the re-flash

Procedure

- Press and hold the keypad ‘*down*’ arrow then connect to either a vehicle diagnostic socket or 12v mains adaptor through the side of the Multi-Cable.
- Continue to hold down arrow down until you see "Slave Update Disabled" followed by the normal Autodiagnos vehicle manufacturer menu
- Release keypad ‘*down*’ arrow.
- Press *F3 (Config)* button
- Select ‘*MT-Pro Menu*’ by pressing Enter
- Scroll down and select "*Flash Slave*" option from the menu.
- A warning message will be shown regarding ‘*forcing slave from current version to later version, do you want to continue?*’ Press YES to continue
- Re-flash procedure will begin to program 5 memory banks
- Once finished the Mt-Pro will re-boot and the procedure is complete

If the above method fails at any stage we recommend repeating the procedure up to 5 times.